
11.0 CONCRETE NAILS

11.1 When pounding concrete nails into hard asphalt or concrete, hold the nail with a pair of vise grips in order to prevent the nail from flying away.

Personal Protective Equipment:

- Hard Hat
- Safety glasses

11.2 PLANTING PINS

When pounding pins, keep hand 0.15 from top of hammer to prevent hitting fingers on top of pin. (Detail A).

When C.S. pin, turn hammer vertical so that you do not hit your hand on edge of hole. (Detail B).

Other PPE. Necessary for task:

1. Gloves
2. Safety glass

DETAIL A

DETAIL B

BEIRSTO LEHNERS KETCHUM
ENGINEERING LTD.

JULY 2007